TNTY GROUP

Ground Fixed Calypso Chimes Page 1 of 4



Instrument Components Per Post:

M6x20 Security Screw



M6 Saddle Strap



x2

M6 Square Nut



1.5m/59"

Beater Holder

Metric Conversion: 250mm/10" 400mm/16" 450mm/18" 1510mm/59" 1195mm/473/64"

Installation Instructions









Weight of heaviest part 7.5kg

- 1. Instrument will arrive on site fully assembled. (1.1) (See Assembly Guide)
- 2. Attach Ground Fixing studs holes in base of centre post (1.2) (See Ground Fix Post Installation Sheet)
- 3.Excavate 1 hole for the Steel legs 250mm diameter by 450mm deep in desired location upon decision from customer.
- 4. Locate (lower) leg into hole, making sure it is vertical and level prior to concreting in place.
- 5. Once happy with location of the Instrument, fill holes using rapid hardening concrete. Be sure to compact concrete around legs and leave to dry according to manufactures guidelines.
- 6. Attach the holder, beater and the saddle strap on each side of the post. (1.3)







Ground Fix





M10 Nut

Assembly Guide PPRCHP







Ground Fixed Calypso Chimes Page 2 of 4



Instrument Components Per Post:


M6x20 Security Screw

M6 Saddle Strap

x2 M6 Square Nut

Beater Holder

Thread Lock Solution Required (Not Supplied)



COMPONENTS LIST:

M10 Nut X4 M10x200 Threaded Bar X2

Saddle Strap X2

M6x20 Pin torx X4

M6 Square Nut X2

Beater Holder X1





Ground Fixed Calypso Chimes Page 3 of 4



Instrument Components Per Post:

M6x20 Security Screw

M6 Saddle Strap


x2

M6 Square Nut

Beater Holder

600mm min spacing

Thread Lock Solution Required (Not Supplied)





Ground Fix Components Per Post: M10x200 Bolt





Spares available from www.musical-play.com or from your local distributor



Ground Fixed Calypso Chimes Page 4 of 4



Instrument Components Per Post:






x4


 $M10\,Nut$


Metric Conversion: 50mm/ 2" 250mm/ 10" 350mm/ 14" 400mm/ 16" 450mm/ 18"


Ground Fix Post Installation




Fix M10x 200 Threaded bar in place using M10 Nuts







Compact base of hole with 50mm of aggregate. Lower ground Fix post attached to instrument into hole (check instrument straight and level before filling with concrete)



400mm min depth