

# Installation Instructions

## Surface Fixed

Freechimes  
Alto/ Soprano  
Page 1 of 3



### Components:

Eye Straps  
X2

M6x20mm  
Secure Screw  
X4

M8x40mm  
Secure Screw  
X4

Metric Conversion:  
1260mm/ 49 39/64"  
1.5m/ 59"

Weight of heaviest part **8.35kg** (Freechimes)

1. Carefully lay 2 x legs on a **level surface** and check distance between **legs is equal**. Line up pre drilled holes in the backboards with the holes in legs and ensure the instrument is aligned square with the legs. **Fix** in place using **M8x40mm screws** supplied (see installation guide)

2. Attach Surface Fixing posts to legs (See **Surface Fix Post Installation Sheet**)


3. **Locate Instrument** in desired location and mark holes to fix to desired surface.

4. **Fix Surface Plate** to level surface using Coachscrews, Rawlbolts, chemical anchors or similar as deemed appropriate by Installer.


(It is your responsibility to ensure that the existing surface is suitable to receive the appropriate fixing)

5. Make sure all fixings are covered and secure using cover caps provided

6. Beaters can be fixed to Steel posts with fixings provided



Install Instrument with 1.5m free space (from widest point) around it.



Pair Small Beaters X1

Surface Fix Components:

x8  
2 Part Cover Cap

x2  
M10 Barrel Nut

x2  
M10x70 Security Screw

Spares available from [www.musical-play.com](http://www.musical-play.com) or from your local distributor

16 Kg

# Assembly Guide PPFREC



## Surface Fixed

Freechimes  
Alto/ Soprano  
Page 2 of 3



### Components:



Eye Straps  
X2



M6x20mm  
Secure Screw  
X4




M8x40mm  
Secure Screw  
X4

Thread Lock Solution  
Required (Not Supplied)

709mm Diatonic Post Centres

472mm Pentatonic Post Centres




Thread Lock Solution  
Required (Not Supplied)

**Tools:**

- x1
- x2

### COMPONENTS LIST:

- Saddle Strap X2
- M6x20 Pin torx X4
- M8x40 Pin Torx X4
- M10x70 Pin torx X2
- M10 Barrel Nut Pin torx X2



Pair Small  
Beaters X1

### Surface Fix Components:

- x8
- x2
- x2

Spares available from  
[www.musical-play.com](http://www.musical-play.com) or  
from your local distributor

16 Kg

# Surface Fix Post Installation



Tools:



## Surface Fixed

Freechimes  
Alto/ Soprano  
Page 3 of 3



## Components:



x2

M10 Barrel Nut



x2

M10x70 Security Screw




x8

2 Part Cover Cap


Thread Lock Solution  
Required (Not Supplied)

1




Locate the Surface fix Plate into the leg of the instrument.

2



Fix instrument to Surface fix plate using M10 bolt and Barrel Nut and use **thread locking solution** to prevent fixings working loose.

3



Fix Surface Plate to the ground surface **Ground Anchors Not provided** cover fixings with caps provided