

Installation Instructions

Ground Fixed

Petal Drum
Page 1 of 3



Weight of heaviest part 7.5kg



1. Attach Petal Drum section to frame with security screws provided. **(1.1)** (See Assembly Guide)



2. Attach Ground Fixing studs holes in base of centre post **(1.2)** (See Ground Fix Post Installation Sheet)

3. Excavate 1 hole for the Steel legs **250mm diameter by 450mm deep** in desired location upon decision from customer.

4. Locate (lower) leg into hole, making sure it is vertical and level prior to concreting in place.

5. Once happy with location of the Instrument, **fill** holes using rapid hardening **concrete**. Be sure to compact concrete around legs and leave to dry according to manufacturers guidelines.

6. Attach the 1 of the beaters to each of the saddle strap on the hex frame. **(1.3)**



Instrument Components:



x4

M6x20 Security Screw



x2

M6 Saddle Strap

Metric Conversion:
250mm/ 10"
400mm/ 16"
450mm/ 18"
1080mm/ 42.5"
1.5m/ 59"



Pair Small Black
Beaters X1

Ground Fix
Components:



x2

M10x200 Bolt



x4

M10 Nut

Spares available from
www.musical-play.com or from
your local distributor

12.5 Kg

Assembly Guide PPPETA




Tools:
 x1
 TX 30 Driver Bit






Install 3X PU Inserts into each arm before installing petal section



Ground Fixed
 Petal Drum
 Page 2 of 3




COMPONENTS LIST:

-  M8x25 Pin torx X3
-  M10 Nut X4
-  M10x200 Threaded Bar X2
-  Saddle Strap X2
-  M6x20 Pin torx X4

Instrument Components:

-  x4
M6x20 Security Screw
-  x2
M6 Saddle Strap

Thread Lock Solution
 Required (Not Supplied)



Pair Small Red
 Beaters X1

Ground Fix Components:

-  x2
M10x200 Bolt
-  x4
M10 Nut

Spares available from
www.musical-play.com or
 from your local distributor

12.5 Kg

Ground Fix Post Installation




Ground Fixed
Petal Drum
Page 3 of 3




Components:




Metric Conversion:
50mm/ 2"
250mm/ 10"
350mm/ 14"
400mm/ 16"
450mm/ 18"




Fix M10x 200 Threaded bar
in place using M10 Nuts




Excavate 1 holes with a
250mm diameter tapering
down to 350mm diameter
and 450mm depth



Compact base of hole with
50mm of aggregate.
Lower ground Fix post
into hole (check
instrument straight and
level before filling with
concrete)



Fix hole with fast drying
concrete to manufacturers
specifications.



400mm min depth