# TNTY GROUP

#### Surface Fixed

Tubular Bells Page 1 of 2



Instrument Components:

Tubular Bells are preassembled

Metric Conversion: 250mm/10" 400mm/16" 600mm/24" 1.5m/59" 2207mm/98"

# Installation Instructions




1. Attach Surface Fixing plates to each of the 9 legs(1.2)


2.Locate each chime in desired location and mark holes to fix to desired surface.

**3**. Fix Surface Plate to level surface using Coachscrews, Rawlbolts. chemical anchors or similar as deemed appropriate by Installer.

(It is your responsibility to ensure that the existing surface is suitable to receive the appropriate fixing)

4. Make sure all fixings are covered and secure using cover caps provided





Weight of heaviest part 10kg (XXL Bell)



1.2

Surface Fix Components:









## Surface Fixed

Tubular Bells Page 2 of 2



### Components:




M10 Barrel Nut

M10x40 Security Screw




2 Part Cover Cap

# Surface Fix Plate Installation



Locate the Surface fix Plate into the leg of the instrument.



Fix instrument to Surface fix plate using M10 bolt and Barrel Nut and use thread locking solution to prevent fixings working loose.

Fix Surface Plate to the ground surface Ground **Anchors Not provided** cover fixings with caps provided